

Cleaning - *It is very important to keep your system clean at all times.*

Clean the CaskWidge system weekly - Use the CaskWidge cleaning brushes for best results

It is advisable to create a permanent clean area in your cellar for your regular cleaning routine. Clean all cellar equipment, before and after use.

*** It is recommended that you wear goggles, rubber gloves and apron during cleaning**



- 1 All parts of the CaskWidge **should be taken apart and put to soak in a non-caustic detergent.** (Follow the manufacturer's instructions on use and handling).

DO NOT OVER SOAK!

- 2 Once soaked, for the recommended time, remove the CaskWidge parts from the detergent, **(use rubber gloves).**
- 3 Now use the CaskWidge Cleaning Brushes to clean the separate parts. **(It's recommended that you wear safety goggles, gloves and the apron to avoid splashes).**
- 4 **Insert the larger Tapered Brush into all the openings on the CaskWidge Tap. Push in and out, scrubbing, until thoroughly clean.**
- 5 Use the small CaskWidge Cleaning Brush to clean all the small openings on the Black 'T' Piece, Float Heads, Pipe Connectors and Black Venting Tap. Insert brush and thoroughly clean.
- 6 Once clean, all parts should be rinsed in clean warm water and then dried.
- 7 **Clean the CaskWidge Float and Piping**
After soaking for the recommended time in the beer line detergent, **remove the Float and Piping. (Use rubber gloves)**
- 8 **Remove the float pipe** from the Float Head or the bottom of the Black 'T' Piece by holding it firmly close to the head and **Twist the pipe to remove easily.** Please be careful not to squeeze the Float-Filter out of shape - **Don Not Force.**
- 9 **Insert the CaskWidge Long Pipe Brush into one end of the Float Pipe and slide along,** keeping your hand close to the pipe entrance while feeding through the metal handle. The brush can be pulled right through using the hooped end to guide it. **(Hang up the Pipe Brush when not in use)**
- 10 **Clean the float-filter agitating it in beer line cleaner,** then check that the metal filter is clear. **Insert the small CaskWidge Cleaning Brush to clean inside if necessary. Rinse in clean warm water, dry thoroughly.**



Store all cleaned parts and spare floats away. (Hang up floats or store in an airtight container.)

Do not leave equipment on the floor.

Note: If an automatic cleaning system is used - we can supply a specific adapter nut for converting our pipe connector to a $\frac{3}{4}$ BPI Internal thread. Please call for details.



CHEERS!

Tel: 08453 707 606
www.caskwidge.com
(for all downloadable user guides)