

PLEASE REMEMBER TO PUT A CLEAN FLOAT ON, IN BETWEEN EACH CASK CHANGE
(To eliminate the risk of cross-contamination between casks.)

Widge Floats are available in 3 pre-cut and colour coded options:



RED FLOAT 9 – 11 gallons



BLACK FLOAT 18 – 22 gallons



CLEAR FLOAT up to 36 gallons (Self Cut)



When using the clear floats, cut the float pipe to length, depending on the size of the cask.

note: pipe length to be cut from pipe end to pipe end, not including float this will ensure the float is in the correct position under the 'top break', see photo.

The pipe can be cut with conventional scissors.

It is essential that the pipe is cut to the correct length cask size (gallons):

4 1/2 gallons:	40cm
9 to 11 gallons:	60cm
18 to 22 gallons:	80cm
36 gallons:	Leave full length

REMEMBER

USE RED FLOAT for 9-10-11gallon casks

USE BLACK FLOAT for 18-22 gallon casks

TECHNICAL TIPS

When removing the float from an empty cask remember the keystone may have hinged. If you feel any resistance - **TWIST, DON'T PULL THE PIPE!!**

When removing the float pipe from either the Float Head or from the bottom of the Black 'T' Piece. Do not pull the tube - this will stretch and tear the tubing. Hold firmly at the contact point and twist the pipe to facilitate ease of removal - **DO NOT FORCE!**



CHEERS!

Tel: 08453 707 606
www.caskwidge.com
(for all downloadable user guides)